

AirBench FP

Construction

This heavy duty AirBench is constructed from welded, formed steel panels, powder coated grey after fabrication. The surface is purpose made 3 mm thick smooth top perforated steel, also powder coated after fabrication.

A rigid clamp bar provides positive filter sealing against soft rubber seals; filters are accessed for cleaning and removal from the top. Filter changes can be accomplished in minutes.

AirBench FP is supplied complete with integral 240 volt fanset with IP56 motor enclosure, on/off switch, 3m mains lead and fused plug for rapid installation and setting to work.

The AirBench FP range is robust and is well suited to continuous, production level use with surface loads up to 150 kg.

Performance and pricing is identical to comparable EX models.

Specifications may vary; contact us on the number below to discuss the correct model and filter selection for your application.



Applications

AirBench FP is available with the following standard filter configurations:

- A Non sparking dusts
- H Fine non sparking dusts
- B Very fine non sparking dusts
- L HEPA filtration
- E Low volume fume
- J High volume fume
- C Light sparks

See separate datasheets for more information.



Accessories

We supply a full range of accessories including:

- Castors
- Remote fans and ducting
- Electronic speed control
- Enclosures
- Spare filters and alternative filter sets
- Hours run meters
- Filter pressure loss gauges

Dimensions

Model	Width	Depth	Height
FP066784	660	670	840
FP126784	1260	670	840
FP186784	1860	670	840
FP129784	1260	970	840
FP189784	1860	970	840